

1

Current Stem position
when you receive
the bike.



2

Remove the bolt
completely with hex
key tool.



3

Connect the spring
to the bolt that has
already been removed.



4

Reattach the bolt
w/ spring to their
original position and
tight it with hex
key tool.



1

Styrfrempind
ved modtagelse.



2

Løsn unbrakobolten
med spændeskive helt.



3

Før bolten med
spændeskive igennem
ringen for enden
af fjederen.



4

Spænd bolten
m/fjederen fast igen
i den nedre del
af styrfrempinden.

